

SUMMER CLASSICS

Four leg X dining table base

ASSEMBLE INSTRUCTIONS

NO.	Parts		Total
A		M6x16	4
B		M8x35	3
C		spring washer M8	3
D		washer M8	3
E		adjustable glide M8x12	4
F		M6	1
G		M8	1
H		M8x50	1

1. Use the 4 (A) bolts to connect the top plate to the shaft.
2. Use the 3 sets of (B,C,D) to connect the shaft to the base plate.
3. Screw in the foot glides (E) into the base plate.
4. Adjust the foot glides to ensure that the table is level.
5. Place umbrella set screw (H) in the threaded hole in the shaft.

